

Stream Protection Act 124 310 Permit General Conditions

- ~~1. Complete work affecting a streambed or stream bank in an expeditious PROMPT? manner to avoid unnecessary impacts to the stream. OMIT 1?~~
2. Limit the clearing of vegetation to that which is absolutely necessary for construction of the project. Take precautions to preserve existing riparian vegetation. Salvage, and reuse, AND PLANT native vegetation where possible.
3. Install and maintain erosion control measures where appropriate to protect aquatic resources. Do not clear and grub land adjacent to streams prior to installing proper erosion and sedimentation controls. Conduct all work in a manner that minimizes turbidity and other disturbances to aquatic resources.
- ~~4. Plan temporary construction facilities to:~~
  - ~~a. Minimize disturbance to stream banks, stream bank vegetation, and the streambed by locating staging or storage facilities at least 50' horizontally from the highest anticipated water level during construction;~~
  - ~~b. not restrict or impede fish passage in streams; and~~
  - ~~c. not restrict any flow anticipated during use.~~
- ~~5. Provide sediment controls for drainage from topsoil stockpiles, staging areas, access roads, channel changes, and instream excavations.~~
- ~~6. Isolate work zones from flowing and standing waters to prevent turbid water and sediments from being discharged into streams or other drainages that flow directly into the stream. Divert flowing waters around the work zone.~~
- ~~7. Do not spill or dump material into streams. Store and handle petroleum products, chemicals, cement and other deleterious TOXIC? materials in a manner that will prevent their entering streams.~~
- ~~8. Do not permit wash water from cleaning concrete related equipment or wet concrete to enter streams.~~
9. Do not operate mechanized equipment in any stream or flowing water unless special authorization is obtained. If special authorization is granted, the following conditions apply:
  - a. Powerwash all equipment allowed in a stream prior to entering the stream channel.
  - b. Clean and maintain all equipment so that petroleum-based products and hydraulic fluids do not leak or spill into the waterway.
- ~~10. Reclaim streambeds and stream banks as closely as possible to their pre-disturbed condition.~~
11. Restore disturbed stream banks to their natural or pre-disturbed configuration to match adjacent ground contours or as specified in the project plans. Stabilize, reseed, and re-vegetate disturbed areas. Install and maintain long-term biodegradable erosion-control measures to protect these areas until adequate vegetation has been established.
- ~~12. Restore temporary access routes and any temporarily disturbed areas to original conditions, including original contours and vegetation.~~
- ~~13. Dispose of any excess material generated from the project above the ordinary high water mark and in an area not classified as a wetland.~~